Radio Ampstik® Radio Linked Multiple Reading Ammeter


Heads-up display for instant confirmation of the reading

Records up to four readings

Remote read out up to 50 feet away

Operates in the 900 MHz non-licensed frequency band

Mount the display on the hotstick or hold in your hand







The Radio Ampstik uses the same current sensor technology as the original Ampstik. The key feature of this unit is the ability to display the current reading up to 50 feet away from the sensor. The user has the option to hold the display in their hands, mount it to a hotstick, or hang it on the

The sensor is based on the SensorLink patented amp inductive sensor, which does not use magnetic materials and has no moving parts. The opening of the sensor is electronically closed and external currents are also electronically rejected. The sensor is not position sensitive; just slip the Radio Ampstik sensor over a conductor to take a measurement.

The sensor for the Radio Ampstik was engineered to optimize a opening of 2.5 inches (6.35 cm), which is very durable and is able to accurately measure from 1 to 5000 amps.

By holding down the switch, the user is able to change between the following modes: Hold up to four readings, to continuously display readings in the RUN mode, to Erase readings, or Power Off the display.

The display will show the current measurement and continue to update the reading three times per second. A single push button switch operates the display.

When in the Hold mode, by pressing and quickly releasing the switch, the user is able to review each of the recorded readings. Taking the data in the hold mode makes it easy to record the measurement for further review.

The Radio Ampstik is the labor saving instrument that every utility personnel will find essential. The combined abilities of being able to easily store and retrieve data, while allowing the user to place the display wherever it is most useful, makes the Radio Ampstik the best answer for quality instrumentation.

Applications

Check current before breaking load

Check for load balance

Check CT Ratios

Conduct load studies

Identify cold load pickup problems



Radio Ampstik®

Radio Linked Multiple Reading Ammeter

	The state of the s
Model Number	6-120 Kit (Includes 8-120 Sensor Transmitter, 8-121 Receiver Display & 7046 Carrying Case)
Frequency	60 Hz or 50 Hz
Measurements	Four Readings
Range of Operation	
Voltage Phase to Phase	0-69 kV
Current	1 - 5000 A
Sensor Opening	2.50 in, 6.35 cm
Resolution	
Amps 0-99.9A	0.1 A
Amps 100-5000A	1 A
Accuracy	
Amps	±1% ±2 digits
EU Standards	Successfully passed international test standards indicated by CE
Mechanical	
Weight	3.0 lbs, 1.37 kg
Controls	One button operation
Operating Temperature	-22 to +140 °F, -30 to +60 °C *
Display	5 Digit LCD
Housing	Shock & water resistant molded urethane
Hotstick Mounting	Universal chuck adapter (Hotstick not included)
Battery	Two each 9V alkaline or 9V lithium
Radio	
Frequency, Region(s) 2 & 3	916.48 MHz
Frequency, Region(s) 1	869.85 MHz
Power	1 milliwatt
Range	50 Feet, 15.24 Meters
· · · · · · · · · · · · · · · · · · ·	

^{*} See the Radio Ampstik user's manual for battery temperature specifications



Toll Free: 1-866-327-8731 1-86-MEASURE-1

Tel: 905-575-1941 Fax: 905-575-0386

E-mail: sales@technical-sys.com web-site: www.technical-sys.com



SensorLink® Corporation